

RIVERSIDE

NAME: RIVERSIDE 500 C6 - Pasting map

PAGE:

IN STORE: W10 2022

CREATION: 2021 01 12

LAST UPDATE: 17.05.2022

by Andrei Tarca



Stick the application tape directly after the welding



Vertically in the middle & Sticked at the top

Headtube

Stick the application tape directly after the welding

Stick the application tape directly after the welding
Aligned with the middle axis of the SIDE view.

Left side

150mm +/-2mm

LEFT SIDE

Pasting map for all sizes.

Paste SATIN chainstay protection decal

DECATHLON

This document is the property of DECATHLON Production all rights reserved

DECATHLON, 4 boulevard de Mons, 59650 VILLENEUVE D'ASCQ, FRANCE