PACE: NAME: RIVERSIDE 500 C4 - Pasting map **RIVERSIDE** CREATION: 2019 IN STORE: W10 2020 LAST UPDATE: 2021 01 29 RS500 Stick the application tape with arrow on top of the welding line. Stick to the welding line Vertically in the middle & Horizontally in the middle 150mm +/-2mm LEFT SIDE Headtube 36mm +/-2mm from the begining of the welding. Stick to the welding Pasting map for all sizes. 150mm +/-2mm Paste chainstay protection decal