PACE: NAME: RIVERSIDE 500 C6 - Pasting map **RIVERSIDE** IN STORE: W10 2022 CREATION: 2021 01 12 LAST UPDATE: 17.05.2022 by Andrei Tarca Headtube Stick the application tape directly after the welding Stick the application tape directly after the welding Vertically in the middle & Sticked at the top Stick the application tape directly after the welding Aligned with the middle axis Left side of the SIDE view. Stick the application tape directly after the welding S, M, L SIZES 150mm +/-2mm ADE IN» STICKE Chainstay decal 15 mm from welding LEFT SIDE Stick the application tape Pasting map for all sizes. directly after the welding Aligned with the middle axis 150mm +/-2mm of the SIDE view. Paste SATIN chainstay protection decal **DECATHLON** This document is the property of DECATHLON Production all rights reserved DECATHLON, 4 boulevard de Mons, 59650 VILLENEUVE D'ASCQ, FRANCE